WOODSTOCK WALLS

WOOD WALL DESIGNS

HARBOR COLLECTION Click&Stick INSTRUCTIONS

- 1. Open box and lay out panels in the shape of the wall. (if applicable, make cuts before the start of your wall for the fastest/easiest installation).
- 2. Put a ¼" bead of Click&Stick adhesive on the backside of the panel per diagram, below.
- 3. Apply wood panel to the wall, level. Add pressure with your hands to make sure adhesive spreads evenly on all individual planks. (if starting in the middle of the wall, use a level to make a reference line).
 - a. If starting in the middle of the wall, wait 20 minutes to make sure your first plank is secure before stacking others.
- 4. Repeat steps 2 & 3 until your wall is complete.

(BLACK LINES ARE REFERENCE FOR ADHESIVE / VIEW FROM BACKSIDE OF PANEL)







